

English	Manual operation of VELUX INTEGRA® roof windows GGL/GGU	2
Deutsch	Coming soon	
Français	Coming soon	
Dansk	Coming soon	
Nederlands	Coming soon	
Italiano	Coming soon	
Español	Coming soon	
Bosanski	Coming soon	
Български	Coming soon	
Česky	Coming soon	
Eesti	Coming soon	
Hrvatski	Coming soon	
Latviski	Coming soon	
Lietuvių	Coming soon	
Magyar	Coming soon	
Norsk	Coming soon	
Polski	Coming soon	
Português	Coming soon	
Română	Coming soon	
Русский	Coming soon	
Slovenščina	Coming soon	
Slovensky	Coming soon	
Srpski	Coming soon	
Suomi	Coming soon	
Svenska	Coming soon	
Türkçe	Coming soon	
Українська	Coming soon	

Manual operation of centre-pivot windows

You can open and close your centre-pivot window manually. If the window is already open, you must close it fully with the wall switch first.

- Open the window by pulling downwards on the control bar of the window.
- Close the window again by pushing the control bar back again.

Note: If you have opened the window manually, you must also close it manually to be able to operate it with the wall switch again. This also applies to enabling operation of programs and to ensure window closes automatically in case of rain.

