


# FML/FMC Electric



**VELUX®**



VAS 455014-2026-03



## VELUX® Electric



PAGES  
4-19

## VELUX INTEGRA®



PAGES  
21-39

VELUX®

XXX XXXX


XXXXXXXXXX  
XX XXXX X

CE 13XX



EN 14351-1-2006+A2:2016

www.velux.com/ce











1







2









3








4








5





6






7





8



9








10











[www.velux.com/electricalsupport](http://www.velux.com/electricalsupport)




11





























1






2






3






4






5







6









7








8








9





10



# 11





# 12












14








[www.velux.com/electricalsupport](http://www.velux.com/electricalsupport)

15









[www.velux.com](http://www.velux.com)



[velux.com/contact](http://velux.com/contact)

**VELUX®**

INSTALLATION INSTRUCTIONS FOR BLACKOUT BLIND FWL/FMC ELECTRIC. ©2018, 2026 VELUX GROUP  
©VELUX, THE VELUX LOGO, IO-HOMECONTROL, THE IO-HOMECONTROL LOGO ARE REGISTERED TRADEMARKS USED UNDER LICENSE BY THE VELUX GROUP