
CVP Electric CFP

Maintenance

CVP Electric

Cleaning the outer glass surface

Cleaning the outer glass surface can be done with a soft, clean, lint-free cloth. Clean water will normally be sufficient for cleaning the glass. Non-abrasive household cleaners can also be used.

The flat-roof window must be closed during cleaning and cleaning should take place from the outside.

Warning

- Avoid contact from silicone with the glazing.
- Do not use any cleaning products containing abrasive particles.
- Do not use household cleaners containing high levels of acid or alkaline for cleaning the glazing. This includes common household cleaners such as methylated spirits.
- Avoid contact with the glazing from all sharp or abrasive objects including jewellery.
- Never attempt to clean off dirt on the glazing without first applying water.
- If any works are taking place near the flat-roof window, protect it to prevent any splashes or staining from aggressive and abrasive compounds damaging the flat-roof window.

Ventilation

To ensure the best possible indoor climate and to prevent condensation, it is recommended to open the flat-roof window two or three times a day for a duration of 15 minutes each time. If the flat-roof window is covered by snow, the snow must be removed from the outside before opening the flat-roof window.

Snow removal on the outer glass

In areas with heavy snowfall, ensure that snow on the outer glass is removed on a regular basis.

Rain sensor

Dirt and snow on the rain sensor may cause operating problems. Therefore, it is recommended to clean the rain sensor with a soft, wet cloth once or twice a year or when needed.

Maintenance from the inside

Cleaning the inside glass surface can be done with a soft, clean, lint-free cloth. Clean water will normally be sufficient for cleaning the glass. Non-abrasive household cleaners can also be used. Otherwise, the flat-roof window is maintenance-free from the inside.

Personal safety

For personal safety, never have your hand or body out of the flat-roof window without switching off the power.



CFP

Cleaning the outer glass surface

Cleaning the outer glass surface can be done with a soft, clean, lint-free cloth. Clean water will normally be sufficient for cleaning the glass. Non-abrasive household cleaners can also be used.

The flat-roof window must be closed during cleaning and cleaning should take place from the outside.

Warning

- Avoid contact from silicone with the glazing.
- Do not use any cleaning products containing abrasive particles.
- Do not use household cleaners containing high levels of acid or alkaline for cleaning the glazing. This includes common household cleaners such as methylated spirits.
- Avoid contact with the glazing from all sharp or abrasive objects including jewellery.
- Never attempt to clean off dirt on the glazing without first applying water.
- If any works are taking place near the flat-roof window, protect it to prevent any splashes or staining from aggressive and abrasive compounds damaging the flat-roof window.

Snow removal on the outer glass

In areas with heavy snowfall, ensure that snow on the outer glass is removed on a regular basis.

Maintenance from the inside

Cleaning the inside glass surface can be done with a soft, clean, lint-free cloth. Clean water will normally be sufficient for cleaning the glass. Non-abrasive household cleaners can also be used. Otherwise, the flat-roof window is maintenance-free from the inside.